

Technical Data Sheet



6049

Satin/Eggshell Acrylic latex

### **INTERIOR**

#### **DESCRIPTION**

Proline 6049 satin / eggshell finish is an acrylic latex paint for interior use. It can be applied directly onto porous surfaces. It is easy to apply, without splashing and dries quickly. It was developed to answer the needs of professional painters. The Proline 6049 can be used for commercial, industrial and residential projects.

# **USE**

This paint is applicable on interior surfaces. Proline 6049 is self-priming and can be applied directly onto porous surfaces. It is recommended for drywall, concrete, galvanized metal, aluminum, masonry, cement and wood. It must be applied onto properly prepared metal surfaces.

## **ADVANTAGES**

- May be applied directly on new drywall
- Excellent hiding, this product will hide most surfaces with two coats or less. A second coat will assure an even finish
- It can easily be cleaned with lukewarm soapy water
- Low spattering, during application, minimal protection is required for baseboards and flooring
- Can easily be sanded after a drying time of 4 hours without overloading the sanding paper.

### **LIMITATIONS**

- Avoid application under 10°C
- Not for exterior application
- Do not use on flooring
- > Wait 30 days before proceeding with the first cleaning

# **TECHNICAL DATA**

Resin			Acrylic Latex	
Color			White, Base	
Cleaning			Water	
Flash point			N/A	
Inflammability			N/A	
Solids by weight			56+/-2	%
Solids by volume			40+/-2	%
VOC			<50	g/l
Gloss	60°		4,0-4,5	%
Sheen	85°		10-13	%
Standards/Certifications	LEED	Eligible for LEED® V4		
	CGSB	Type 1GP 100, 1 GP 209		

# **APPLICATION DATA**

At 25° Celsius							
Relative humidity at 50%							
May differ depending on the colour							
Spreading Rate May vary depending on the surface				37-46 m2 (400-500sqft)	gallon		
Film Thickness	Wet			3,2-4,0	mils		
	Dry			1,25-1,56	mils		
<b>Drying Time</b> Tack free			30	min			
	Recoat			4	hours		
	Cleaning			30	days		
	Cure			30	days		
Application	Brush			V			
	Roller			15	mm		
Max dillution 10%	Spray* N	ozzle:	0.017 – 0.021*	2000-2500	lb/po <sup>2</sup>		
*These data may vary depending on the equipment manufacturer							
Exterior				N/A			
Storage	Temperati	ure		10-30	°C		
Tinted Bases Formats							
	946ml :	3,78L	18,9L				
6049-0 White			1				
6049-1 Base P			1	max. 2 oz de colorant / 3,78 L			





6049

Satin/Eggshell Acrylic latex

## **INTERIOR**

## **SURFACE PREPARATION**

The surface must be dry and clean, without dust, oil, grease, rust and soap. On painted surfaces, it is recommended to clean with a degreaser (T.S.P.) in order to eliminate any contaminant that may affect the adhesion or the curing of the product. Thoroughly rinse the entire surface. The surfaces must be well sanded and dusted.

**Presence of mold:** Clean the affected area with a mixture of 1 part bleach to 3 parts water. Thoroughly rinse the entire surface.

**Flaking or peeling paint**: Using a scraper, remove the weakened and/or loose paint, then sand the edges of the surface to make it smooth.

A repair compound should be used to fill holes and uneven surfaces. Sand with a grade #100 sanding paper.

**New drywall**: To avoid creating an undesirable texture on the drywall, the joint compound must not be sanded excessively. **Concrete / Masonry**: Wait until the concrete and/or masonry has cured at least 30 days before painting it.

Aluminum, galvanized metal, and interior ferrous metal: Remove all traces of oxidation (rust), then clean with Metal Plus 467. metal conditioner.

**Wood:** The surface must be sanded with a grade #80 or #100 sanding paper to improve adhesion.

## **RECOMMENDED PRIMER**

**Drywall**: May be applied directly on new drywall or use primers; Proline 6070 or Proline Eco 7070.

**Concrete block / rough brick:** Apply the Proline 6006 block filler to level the surface or apply the Proline 6049 directly.

**New Concrete**: Apply the Proline 6049 directly onto the surface.

**New wood:** Use the Adhero Plus 290 or Adhero Hybrid 297. **Pine knots**: Seal the pine knots with the Stop Plus 298.

**Red cedar and redwood**: Apply one to two coats of Block Plus 296 alkyd based.

**Aluminum, galvanized metal:** Apply a coat of Adhero Plus 290 or Metal Plus 4700 white

Interior ferrous metal not rusted: Adhero Hybrid 297

Latex paint: No primer is required.

**Alkyd paint**: Apply an undercoat of Adhero Plus 290\* or Adhero Hybrid 297.

\*See limitations for Adhero Plus 290.

## **APPLICATION**

This product is ready to be used and does not require dilution. Mix well before use. Apply one coat or two if necessary. Allow a minimum drying time of 4 hours between each coat for pale colours and 8 hours for dark colours. In order to properly cover the surface, it is recommended to use a 15mm lint free roller and a quality nylon-polyester brush. Clean the brushes and rollers with lukewarm soapy water following their use.

For spray application: May be diluted with a maximum of 10%

water

Pressure: 2000 to 2500 lb/in2\*

**Nozzle**: 0.017 – 0.021\*

\*This data may vary depending on the brand of the equipment manufacturer.

### **MAINTENANCE**

This paint requires 30 days drying time before proceeding with a first cleaning. Only use mild, non-abrasive cleaners and a soft cloth. Clean the surface with a light, circular motion

### **WARRANTY**

This product will give full satisfaction if applied according to the manufacturer's instructions. Manufacturer's liability is limited to the replacement of the product and does not include manpower if found defective upon inspection.

#### **CAUTION**

- Keep away from children's reach
- Keep lid closed when not in use
- Avoid freezing

Contact your municipality to dispose of the container in an environmentally-friendly manner.