



7052
Eggshell
Acrylic Latex

Technical Data Sheet

INTERIOR

DESCRIPTION

Eco 7052 eggshell finish is a Zero VOC acrylic latex paint for interior use. It can be applied directly onto porous surfaces. It is easy to apply, without spattering and dries quickly. It was developed to answer the needs of professional painters. Proline Eco 7052 can be used for commercial, industrial and residential projects.

USE

Proline 7052 can be applied on porous surfaces. It is recommended for drywall, concrete, galvanized metal, aluminum, masonry, cement and wood. Offering a good resistance with an easy cleaning.

ADVANTAGES

- It is ideal for LEED projects or any other projects requiring Zero VOC paints.
- Allows walls and ceiling applications, due the low sheen
- Does not require the use of a primer sealer on new drywall
- Provides a smooth surface with a minimum of texture.
- can easily be sanded after 4 hours drying time without overloading the sanding paper.

LIMITATIONS

- Avoid application in all temperatures under 10°C
- Do not use on flooring
- Not for exterior application

TECHNICAL DATA

Resin	Acrylic Latex		
Color	White, P.base		
Cleaning	Water		
Flash point	N/A		
Inflammability	N/A		
Solids by weight	55 ±2	%	
Solids by volume	40 ±2	%	
VOC	Zero VOC	g/l	
Gloss	60°	2,0-3,0	%
Sheen	85°	3,0-5,0	%
Standards/Certifications	LEED	Eligible for LEED® v4	

APPLICATION DATA

At 25° Celsius			
Relative humidity at 50%			
May differ depending on the colour			
Spreading Rate <small>May vary depending on the surface</small>		33-42 m ² (350-450sqft)	gallon
Film Thickness	Wet	3,55-4,55	mils
	Dry	1,42-1,82	mils
Drying Time	Tack free	30	min
	Recoat	4	hours
	Cleaning	30	days
	Cure	30	days
Application <small>Max dilution 10%</small>	Brush	√	
	Roller	15	mm
	Spray* Nozzle: 0.017 - 0.021*	2000-2500	lb/100 ²
<small>* These data may vary depending on the equipment manufacturer</small>			
Exterior application and condition	N/A		
Storage	Temperature	10-30	°C
Tinted Bases	Formats		
	946ml	3,78L	18,9L
7052-0 White			√
7052-1 Base P			√
<small>The Proline Eco will no longer be a 0VOC paint when add colorants</small>			
<small>max. 2 oz of colorant/3,78 L</small>			



7052
Eggshell
Acrylic Latex

Technical Data Sheet

INTERIOR

SURFACE PREPARATION

The surface must be dry and clean, without dust, oil, grease, rust and soap. On painted surfaces, it is recommended to clean with a degreaser (T.S.P.) in order to eliminate any contaminant that may harm the adhesion or the curing of the product. Thoroughly rinse the entire surface. The surfaces must be well sanded and dusted.

Presence of mold: Clean the affected area with a mixture of 1 part bleach to 3 parts water. Thoroughly rinse the entire surface.

Flaking or peeling paint: Using a scraper, remove the weakened and/or loose paint, then sand the edges of the surface to make it smooth.

A repair compound should be used to fill holes and uneven surfaces. Sand with a grade #100 sanding paper.

New drywall: To avoid creating an undesirable texture on the drywall, the joint compound must not be sanded excessively.

Concrete / Masonry: Wait until the concrete and/or masonry has cured at least 30 days before painting it.

Aluminum, galvanized metal, and interior ferrous metal: Remove all traces of oxidation (rust), then clean with Metal Plus 467, metal conditioner.

Wood: The surface must be sanded with a grade #80 or #100 sanding paper to improve adhesion.

RECOMMENDED PRIMER

Drywall: Not needed or use primer Proline Eco 7070.

Concrete block / rough brick: Not needed or apply the Proline 6006 block filler to level the surface

New Concrete: No primer is required.

New wood: Use the Adhero Plus 290 or Adhero Hybrid 297.

Pine knots: Seal the pine knots with the Stop Plus 298.

Red cedar and redwood: Apply one to two coats of Block Plus 296 alkyd based.

Aluminum, galvanized metal: Apply a coat of Adhero Plus 290 or Metal Plus 4700 white.

Interior ferrous metal not rusted: Adhero Hybrid 297

Latex paint: No primer is required.

Alkyd paint: Apply an undercoat of Adhero Plus 290* or Adhero Hybrid 297.

*See limitations for Adhero Plus 290.

APPLICATION

This product is ready to be used and does not require dilution. Mix well before use. Apply one coat or two if necessary. Allow a minimum drying time of 4 hours between each coat for pale colours and 8 hours for dark colours. In order to properly cover the surface, it is recommended to use a 15 mm lint free roller and a quality nylon-polyester brush. Clean the brushes and rollers with lukewarm soapy water following their use.

For spray application: May be diluted with a maximum of 10% water.

Pressure: 2000 to 2500 lb/in²*

Nozzle: 0.017 – 0.021*

*This data may vary depending on the brand of the equipment manufacturer.

MAINTENANCE

Allow 30 days drying time before proceeding with a first cleaning. Only use mild, non-abrasive cleaners and a soft cloth. Clean the surface using a light, circular motion.

WARRANTY

This product will give full satisfaction if applied according to the manufacturer's instructions. Manufacturer's liability is limited to the replacement of the product and does not include manpower if found defective upon inspection.

CAUTION

- Keep away from children's reach
- Keep lid closed when not in use
- Avoid freezing

Contact your municipality to dispose of the container in an environmentally-friendly manner.